


Wall Mount

INSTALLATION GUIDE

Model.ELQMEDTILT



Hardware List:



ID	Qty	Description
1	2	Bracket
2	1	Wall mount
A	4	M4*20mm bolt
B	4	M6*25mm bolt
C	4	M8*25mm bolt

ID	Qty	Description
D	4	$\phi 18 \times \phi 8.5 \times 10$ spacer
E	8	M6 washer
F	4	$\phi 6 \times 40$ Wall anchor
G	4	St6 $\times 50$ bolt

1




Fig 1



Fig 2



Fig 3

2




Fig 4




Fig 5



Fig 6

3




Fig 7




Fig 8



Fig 9

4




Fig 10




Fig 11

Safety Instructions

Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instruction and warnings, please contact your local distributor for assistance.

CAUTION: Use with products heavier than the rated weights indicated may result in instability causing possible injury.

- Mounts must be attached as specified in assembly instructions. Improper installation may result in damage or serious personal injury.

- Safety gear and proper tools must be used. This product should only be installed by professionals.

- This product is designed to be installed on wood stud walls, solid concrete walls or brick walls.

- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.

- Use the mounting screws provided and **DO NOT OVER TIGHTEN** mounting screws.

- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.

- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.

MAINTENANCE: Check that the bracket is secure and safe to use at regular intervals (at least every three months).